

Brandt Auger Hopper Installation
IMPORTANT NOTE BEFORE STARTING
DO NOT REMOVE SAFETY SCREENS



STEP 1

Remove Brandt hitch, then remove the two bolts holding the screen in place as well as the hair pin.



STEP 2

Align the adaptor holes with the screen holes. Bolt-in place using 1/2" x 3 3/4" Carriage bolts provided. (note you need to reuse the nuts that were removed from the screen shown in step 2-3)





STEP 3

Remove the ratchet strap bolts, place the ratchet strap facing outward.



STEP 4

Slide the hopper over the adapter and tighten the ratchet strap. (Some help required)



STEP 5

Place the tow hitch into the receiver and install the pin.



Your new hopper is installed!

